

# **TIRE INFLATION GAUGE TECHNOLOGY**

5

## **37 C.F.R. §1.71(e) AUTHORIZATION**

10 A portion of the disclosure of this patent document contains  
material which is subject to copyright protection. The copyright owner has  
no objection to the facsimile reproduction by anyone of the patent  
document or the patent disclosure, as it appears in the US Patent and  
Trademark Office patent file or records, but otherwise reserves all  
copyright rights whatsoever.

15

## **CROSS-REFERENCE TO RELATED APPLICATIONS, IF ANY**

Not applicable.

20

## **STATEMENT REGARDING FEDERALLY SPONSORED RESEARCH OR DEVELOPMENT**

25

Not applicable.

## REFERENCE TO A MICROFICHE APPENDIX, IF ANY

5                   Not applicable.

## BACKGROUND

### 1.       Field.

10               The present invention relates, generally, to measurement apparatus  
and methods. More particularly, the invention relates to tire pressure  
measurement apparatus and methods. Most particularly, the invention  
relates to a system, apparatus and method for measuring or gauging the  
inflation pressure of tires on or used for specialty and high performance  
15               vehicles. The invention is especially suitable for high performance racing  
automobile tires. The techniques of the invention can also be used in other  
fields wherein inflation or pressurization of articles, particularly inflatable  
articles, is required, such as but not limited to, aviation, aeronautics,  
military technology and the like.

### 20               2.       Background Information.

Existing technology, in general, includes various apparatus and/or  
methods for gauging the inflation pressure of pneumatic articles such as  
tires. In the past, the inflation pressure tires of cars, trucks, industrial or

agricultural machinery, tractors, buses, carts, aircraft, motorcycles,  
scooters, bicycles and the like have been measure with mechanical and  
pneumatic means. These means are satisfactory for most tire applications.  
However, specialized tires on specialty vehicles such as high performance  
5 racing automobiles and aircraft for example, have specialized inflation  
needs for which traditional means are unsatisfactory. In particular,  
inaccuracies in inflation pressure of tires negatively effects the  
performance of high performance racing tires running at high speeds and  
high temperatures. Thus, the tires of racing vehicles must be checked  
10 frequently and quickly. Also, racing vehicle tires often require specialized  
inflation tuning, especially in situations where vehicles turn in one or  
predominantly one direction only, such as on oval race tracks or courses.

The above described background technology is believed to have  
significant limitations and shortcomings in terms of providing an optimum  
15 combination of functionality, reliability, and speed and ease of use. Thus,  
a need exists for the present invention.

All US patents and patent applications, and all other published  
documents mentioned anywhere in this application are hereby incorporated  
by reference in their entirety.

20

## BRIEF SUMMARY

The present invention provides an inflation gauge apparatus and method which is practical, reliable, accurate and efficient, and which is believed to fulfil a need and to constitute an improvement over the background technology.

5           In one aspect, the invention provides an inflation gauge apparatus comprising a pressure transducer; a control system communicatively connected to the pressure transducer; and a display communicatively connected to the control system that indicates at least four pressure readings at the same time.

10           In another aspect, the invention provides a memory tire pressure gauge apparatus for use with race cars, comprising:

- (a)     a pressure transducer adapted for communicative connection to a tire of a race car;
- (b)     a control system communicatively connected to the pressure transducer, the controller receiving tire pressure reading signals from the pressure transducer and converting them to tire pressure display signals, the controller having memory for storing a plurality of tire pressure reading signals; and
- 15
- 20           (c)     a display communicatively connected to the control system that indicates at least eight tire pressure readings simultaneously, the eight tire pressure readings corresponding to a first, relatively cold, tire pressure

reading with respect to a first or initial time and a second,  
relatively hot, tire pressure reading with respect to a second  
or later time for each of four tires, the display further  
showing, simultaneously, four tire pressure change readings  
5 corresponding to changes with respect to time of each of  
the tires caused by use, and heating, of the tires, the display  
receiving tire pressure display signals from the control  
system.

The aspects, features, advantages, benefits and objects of the  
10 invention will become clear to those skilled in the art by reference to the  
following description, claims and drawings.

## BRIEF DESCRIPTION OF THE SEVERAL VIEWS OF THE 15 DRAWING

The present invention, and the manner and process of making and  
using it, will be better understood by those skilled in the art by reference to  
the following drawings.

20 Figure 1 is a perspective view of an embodiment of the inflation  
gauge apparatus and method of the invention.

Figure 2 is a perspective view of an embodiment of the control box of the apparatus.

5 Figure 3 illustrates an embodiment of the control panel of the control box.

Figure 4 illustrates an embodiment of hyper terminal display data generated by the apparatus of the invention and displayed on an exemplary computer communicatively connected to the apparatus.

10

Figure 5 illustrates an embodiment of the lap timer display readout.

Figure 6 illustrates an embodiment of printouts of the lap time and air pressure data from a printer connected to an embodiment of the apparatus of the invention.

15

Figure 7 is a perspective view of an embodiment of the housing base element.

20 Figure 8 is a top plan view of the housing base.

Figure 9 is a side elevation view of the housing base.

Figure 10 is a perspective view of an embodiment of the housing top element.

Figure 11 is a top plan view of the housing top.

5

Figure 12 is a side elevation view of the housing top.

Figure 13 is an end elevation view of the housing top.

10            Figures 14 a and b are schematic views of an embodiment of the circuitry of the apparatus.

#### DETAILED DESCRIPTION

15

**Figure 1-5,** show an embodiment of the tire purging and inflation apparatus of the present invention, generally indicated by the reference numeral 10. The embodiments of the invention described is intended to be illustrative and not to be exhaustive or limit the invention to the exact forms disclosed. The embodiments are chosen and described so that persons skilled in the art will be able to understand the invention and the manner and process of making and using it.

20

The article inflation gauge apparatus 10 and method is compact for easy storage and transport. The inflation gauge apparatus 10 is useable to easily, quickly and portably measure the contained pressure of articles, preferably inflatable articles such as tires. Inflation pressure capabilities range from near 0 to 100 pounds per square inch (PSI) with an accuracy of +/- 0.5% of applied pressure.

### STRUCTURE

Referring to **Figure 1**, the tire inflation gauge apparatus 10 basically comprises a control unit 11 and a connection hose 12. The connection hose 12 includes a flexible hose member 13 of a predetermined length of approximately two feet. The hose member 13 has proximal end which is communicatively coupled to the control unit 11 by a connector 14. A tire coupler 15 is connected to the distal end of the hose member 13.

**Figures 2 and 3** show an embodiment of control panel 20 of the control unit 11. The panel 20 has several switches or buttons, and at least one display 21 a and b. The switches preferably include an ON/OFF switch 22, a MODE switch 23, a CLEAR MEMORY switch 24, STORE MEMORY switch 25, a pair of READ switches 26, a pair of RE-READ switches 27s, numerical key pad digits (1-10) 28, a CLEAR DISPLAY switch 29, a PRINT switch 30, and a BACK LIGHT switch 31. Switches are preferably membrane type switches, although other types of switches may be used consistent with the invention. The displays 21 are preferably



24 character displays. Preferably, the displays 21 are LCD type displays although other types of displays may be used consistent with the invention. In a pressure gauging mode, each display 21 displays first and second pressure readings for two tires and the gain (positive or negative difference) between each first and second reading. Thus, for example, display 21a shows the first or cold reading for the left front tire (LF), the second or hot reading for LF, the gain (difference in temperature) between the first and second readings for LF, the first or cold reading for the right front tire (RF), the second or hot reading for RF, and the gain between the first and second readings for RF. Display 21b shows the first or cold reading for the left rear tire (LR), the second or hot reading for LR, the gain (difference in temperature) between the first and second readings for LR, the first or cold reading for the right rear tire (RR), the second or hot reading for RR, and the gain between the first and second readings for RR. Preferably, symbols or markings are placed on the panel 20 adjacent to the displays 21 for ease of operator reading.

The displays 21a and b are capable of displaying at least four pressures at one time corresponding to pressures of each of four tires with respect to a point in time. Preferably, the displays 21 display eight pressures at one time corresponding to pressures of each of the four tires at two different times. Most preferably, the displays 21 additionally show four pressure change readings corresponding to the changes with respect to time of each of the four tires. Storage capability of the apparatus permits

storing of a plurality of total readings (4 cold, 4 hot, and 4 changes), for example ten (10), which may be recalled on the displays 21. The unitary design of the control panel 20 with displays or a display which indicates a plurality of readings from a plurality of articles, for example cold pressure, hot pressure and pressure change from each and every tire of a race car permits race technicians to determine tire performance quickly and efficiently and thus enables faster and more efficient tuning of the car's tires.

**Figures 7-9** show an embodiment of the housing base 40 of the control unit 11. The housing base 40 is shown to have a rectilinear, preferably rectangular, configuration with a bottom panel 41 and low profile side panels 42a-d. Aperture 43 disposed in side panel 42a accepts proximal connector 14. Aperture 44 accepts a serial connector (not shown).

**Figures 10-13** show an embodiment of the housing cover 50 of the control unit 11. The cover 50 is shown to have a rectilinear, preferably rectangular, configuration which is designed to mate with the housing base 40. The cover 50 has a top panel 51 and low profile side panels 52a-d. Apertures 53 a and b permit viewing of displays 21 a and 21 b respectively.

**Figure 14a/b** show an embodiment of the electronic circuitry 60 of the control unit 11. The circuitry 60 comprises a microprocessor or controller 61 and a battery 62.

The microprocessor 61 controls the elements of the circuitry.

The control panel 20 preferably has a back light for viewing the panel 20 in dark or low light conditions. The back light is actuated by pressing a button 31 on the panel 20. Preferably, it has a control feature  
5 which automatically turns off the light after a predetermined period of time, for example approximately two minutes, to preserve battery power.

The output receptacle is for connecting a printer, computer or other serial peripheral device. The receptacle accepts 3.5mm mini-plugs. The outer ring is GND, the middle ring is TXD and the center post is CTS.  
10 Output is standard RS232 format with 8 data bits, no parity and one stop bit. The baud rate of the serial output is adjustable to match the rate of the peripheral device at 1200, 2400, 4800, 9600, 19200 and 38400. Rate is selectable by pressing MODE and then PRINT. Keys 1-6 are used to select a rate and any key is pressed to exit. PRINT is pressed to print a  
15 ticket for example of the current display data. Print formats for "Air" and "Lap Time" are shown in **Figure 6**.

Referring to **Figure 4**, display data may be communicated to a computer connected via the serial data receptacle. Information may be transferred via HyperTerminal feature of Microsoft Windows 95, 98, and  
20 NT. Typically this program is started by this sequence: Start Menu---Program---Accessories---HyperTerminal---HyperTerminal. After making the connection from your Lap Timer to the computer, follow steps (*The*



immediately after use or otherwise a predetermined period of time after a cold condition readings are previously taken. The zero mode is used to zero the gauge apparatus with no pressure. Switch units mode permits switching or conversion of units of pressure measurement. Lap timer mode permits entering of lap times for correlation of tire pressures with lap times (and indirectly vehicle speed). Lap recall mode permits viewing of saved lap times. Print mode permits selection of baud rate for printouts to match particular printers.

## 10 **Tire Pressure Measurements**

To measure tire pressures on tires and to measure changes in pressures from a relatively cold (before use) state to a relatively hot (after use) state:

1. Press and hold (for about 1 sec) the ON/OFF key to turn the Memory Tire Gauge on.
2. Press CLEAR DISPLAY if there are any readings displayed which need to be cleared.
3. Decide on an order to take measurements. The default order to take readings is RF, RR, LR, LF. The first 4 readings correspond to the "OUT/COLD" readings, located on the top row of the display. The next 4 readings will be in the same order but will correspond to the "IN/HOT" readings which are located on the bottom row of the displays. See the "Read in any Order" section for alternatives to this order. The active position will have a right pointing arrow or a left pointing arrow next to the number. After each "IN/HOT" reading is completed, the "gain" is displayed in parentheses:

$$\text{gain} = \text{IN/HOT pressure} - \text{OUT/COLD pressure}$$

- 5
4. Place the air chuck onto the tire stem and press the READ key to record the pressure. The display will advance to the next open spot. If it is believed that a bad or mistake reading has been taken, the operator may press RE-READ to back up one reading.
  5. When completed taking a set of readings the operator may store the readings in one of the 10 tire memory banks.

## 10 **Tire Pressure Data Storage**

To store measurement data in memory:

- 15
1. Press the STORE MEMORY key to store the current readings so they can be recalled later. The Tire Gauge will display "STORE TIRE READINGS IN WHICH MEMORY LOCATION? ENTER 1-10 TO SAVE (OPEN SPOTS: 12 4567 910)". The bottom line displays which memory locations are currently open. In the above example, only spots 3 and 8 have data stored, with the remaining spots open and available for use.
  2. Press 1-10 to save the current readings to that memory slot, or press any other key to exit this screen without saving. After saving, the Tire Gauge will return to normal mode. NOTE: If you select a memory spot that already has data (such as spot 3 in the above example), the operator will be prompted with the display: "MEMORY LOCATION #03 ALREADY HAS DATA. PRESS [STO MEM] TO OVERWRITE (ANY OTHER KEY TO EXIT)".
  3. Press "STORE MEMORY" to save over that spot, press any other key to return to normal mode.

35 To clear stored data from memory:

- 40
1. Press the CLEAR MEMORY key to clear the readings from a specific memory location. The Tire Gauge will ask "CLEAR TIRE READS FROM WHICH MEMORY LOCATION? ENTER 1-10 TO CLEAR (ANY OTHER KEY TO EXIT)".
  2. Clear one of the ten memory locations by pressing the corresponding number (1-10) on the keypad. The Tire Gauge will then return to Normal mode.
- 45

To recall data from memory:

1. Press the number of the memory location (1-10) desired to be viewed (must be in normal mode to do this). For example if '3' is pressed, the display will read "RECALLING PRESSURES FROM TIRE MEMORY #03, PRESS [READ] TO CONFIRM(ANY OTHER TO EXIT)".
2. Press the READ key to confirm the recall, or press any other key to exit to normal mode.

To clear display of all readings:

1. Press CLEAR DISPLAY. If readings exist since a last save, the Tire Gauge will ask: "DO YOU WANT TO SAVE YOUR CURRENT READINGS? PRESS [STO MEM] TO SAVE PRESS [CLR DIS] TO CLEAR".
2. Press CLEAR DISPLAY a second time to clear the display, or press STORE MEMORY to store your current readings to one of the 10 memory slots (*See the Store Memory section*). Any other key pressed at this screen will bring the operator back to normal mode with the current readings still intact.. Memory Tire Gauge, Users Manual

## **Measurement Units:**

The Memory Tire Gauge can display in the following units: PSI, BARS, or KG/CM2. To switch to a different unit of measurement:

1. Press MODE, then
2. Press '4' for "SWITCH UNITS".
3. Press: '1' for PSI, '2' for BARS, or '3' for KG/CM2. The pressure unit setting will be saved in memory and the Tire Gauge will return to Normal Mode.

## **Read/Measurement Order**

The default order to take tire pressure measurements is:

OUT/COLD: RF, RR, LR, LF then IN/HOT: RF, RR, LR, LF. To take measurements in any order:

1. Press the RF, RR, LR, LF (right front, right rear, left rear, left front). These keys allow the user to measure the tires in any order that is desired.
2. To take readings from a specific tire press the key that corresponds to the desired tire. That tire's readings will be cleared, and the cursor will show the active pressure reading.
3. To start reading at the IN/HOT locations: press MODE, then press '2' for "HOT TIRE PRESSURES". The IN/HOT pressures will be read first, and the OUT/COLD pressures will be read next.
4. To start reading at the OUT/COLD locations: press MODE, then press '2' for "COLD TIRE PRESSURES". If RE-READ is pressed after manually moving to another position, the active cursor will move one spot back in the reverse default order. Memory Tire Gauge, Users Manual

### Lap Timing Measurements

To record lap times:

1. Press MODE and then '5'. The Tire Gauge has 4 independent lap timers that can be displayed all at once.
2. To start one of the four lap timers, press the corresponding number (1-4) on the numeric keypad.
3. The next time the operator presses numbers 1-4, the current lap time will start over at 0:00 and the lap that was just timed will display on the right side of the display.
4. If the operator wishes to stop one of the lap timers without starting the timing for the next lap, press the corresponding number key below keys 1-4. For example, to stop lap timer #2 press the '7' key.

Referring to **Figure 5**, lap times will be saved in memory until you clear them. All lap times will be saved in memory until you clear them.

### TOP DISPLAY

40

		last lap #	last lap time
#1:	00:45.30	L01	01:29.68
#2:	01:12:02	L01	01:35.12
car #	minutes/seconds/hundredths		



Split times can be viewed (but not saved) by pressing and holding the READ key. The current lap time is still running in the background and returns to the display when the READ key is released.

5

5. Press MODE to exit from Lap Timer and go back to the Mode menu. Whenever one reenters Lap Timer mode, the timers will be reset to 00:00.00 but the last lap recorded will be displayed on the right. *Note: If the Tire Gauge is turned off in Lap Timer mode, the Tire Gauge will default to Lap Timer mode when turned on again.*

10

To clear lap times, the apparatus must be in Lap Timer or Lap Recall Mode:

15

1. Press MODE and '5' to get into lap timer mode.
3. To clear a lap time press CLEAR MEMORY (or CLEAR DISPLAY). The Tire Gauge will display "CLEAR THE LAP TIMES OF WHICH CAR NUMBER?"
3. Enter keys 1, 2, 3, or 4 to clear that car number's lap time. Press any other key to exit.

20

To recall lap times the apparatus is set to Lap Recall Mode.

25

1. Press MODE and then '6'.
2. To recall a specific car's lap times select the car number by pressing keys 1, 2, 3, or 4.
3. Scroll through the lap times by pressing the LF and RF keys. To scroll by 10's use the LR and RR keys. Memory

30

Tire Gauge, Users Manual

Although the apparatus and method has been described in connection with the field of vehicle tire inflation, it can readily be appreciated that it is not limited solely to such field. The apparatus and method of the invention can be adapted to purge and/or fill various types

35

of articles, particularly inflatable, pneumatic or other flexible or elastomeric articles.

The descriptions above and the accompanying drawings should be interpreted in the illustrative and not the limited sense. While the invention has been disclosed in connection with an embodiment or embodiments thereof, it should be understood by those skilled in the art that there may be other embodiments which fall within the scope of the invention as defined by the claims. Where a claim, if any, is expressed as a means or step for performing a specified function it is intended that such claim be construed to cover the corresponding structure, material, or acts described in the specification and equivalents thereof, including both structural equivalents and equivalent structures, material-based equivalents and equivalent materials, and act-based equivalents and equivalent acts.